


Vault



Lithium Lens Upgrade

Objectives

Produce a reliable 1 cm. radius, 100 kg/cm lithium lens


Solid lithium lens


- Disassemble and analyze lenses that have failed
- Create an ANSYS model to better understand mechanical stresses
- Review and improve quality control during lens assembly
- Create an alternative lens design

Liquid lithium lens


- R&D effort at BINP, Novosibirsk
- After successful test, significant effort required to modify apparatus

Lens Gradient vs. Measured Debuncher Yield






Lithium Lens Gradient vs. Antiproton Yield



Observed Lens Lifetime

Lens Gradient (T/m)	Average Pulses to Failure
1,000	< 500,000
900	1,000,000
800	3,000,000
740	9,000,000
700	> 10,000,000

Lithium Lens Lifetime



Lithium Lens Upgrade

ANSYS summary for current lens

Analysis of thermal analogue completed and report written
Indicates relatively moderate cyclic stresses, well below fatigue limit
Evidence of lithium separation from titanium septum at high gradient
Model is being refined to include more realistic material properties
Need to understand differences between model and autopsy results
Investigate loads on 18 cm. "long" lens

Lithium Lens Upgrade

Autopsy results

Lenses scheduled for disassembly and analysis

- Lenses #20 and #21, #26 and Russian lens completely done

- Lenses #17 and #18 disassembled, awaiting analysis

- Lens #16 awaiting disassembly

- Lens #22 cooling down

Two general failure modes to inner septum

- Axial intergranular fracture followed by a ductile fracture

 - Intergranular nature of crack more consistent with corrosion*


 - Length of ductile fracture consistent with lower loads from ANSYS*

- Circumferential channels burned through septum


 - Suggests internal arcing, possibly from Li/Ti separation*

 - Small cracks may be obliterated after arcing begins*

Multiple cracks and pits found on inside surfaces of septa



#21




#20

NOV 30 2001
13:44:47
PLOT NO. 1

1 MODAL SOLUTION

STEP=7
SUB =4
TIME=7
NLSEPL (AVG)
DMX =.261E-03
SMN =.607E+09
SMX =.101E+10



.607E+09 .651E+09 .696E+09 .784E+09 .828E+09 .873E+09 .917E+09 .961E+09 .101E+10
Lens crack KINH 8,000 psi int (cycle)




FIGURE 2 Magnification 200 (x) 2000 (x) (cont.)
 Pseudomonas showing the irregular and dark marks identified as 2X
 mycelium on the other side of the membrane of 200 (x)





FIGURE 4 Magnification 200 (x) 2000 (x) (cont.)
 Pseudomonas showing the irregular, branching, and irregularly identified as 10
 mycelium on the other side of the membrane of 200 (x)



Lithium Lens Upgrade

Quality Control Improvements

Lens Fill

- Added instrumentation to lens body
- Improved data acquisition
- Changed strain gauges to improve accuracy
- Pressure transducers upgraded
- Created dummy lens to calibrate instrumentation
- R&D of lens seals and lithium properties

Lens Preparation

- Improved electron beam welding techniques
- Lithium handling procedures changed to minimize contamination
- Created new septum cleaning procedures to avoid stress-corrosion cracking

Lithium Lens Upgrade

Prototype High Gradient Lens

Description

- Lens body and septum both made of titanium

- Eliminates complicated seal between septum and seal body

- Diffusion bonding utilized for joining titanium pieces

 - Possible problems with integrity of central bond

 - Fatigue testing of diffusion bonded samples underway

- Septum construction simplified

- Thicker inner septum

- First generation diffusion bonded lens is in final machining stage

- Second generation design eliminates central joint


ANSYS analysis

- Analysis completed, report forthcoming

- Model needs same refinement as current analysis

- Indicates Li/Ti separation problem and stresses similar to current lens

High Gradient Solid Lens Prototype Design



Lithium Lens Upgrade

Liquid lithium lens

Advantages

- Lower mechanical stresses on septum from lithium in liquid state
- Functional buffer volume to reduce pressure from thermal expansion
- Liquid lithium circulated to remove heat from lens
- Better regulation of lens preload

Disadvantages (don't get me started)

- Challenges associated with circulating liquid metal
- Locking valves required to prevent damage to circulating system
- Reliability of such a complex system will probably be much lower
- Elaborate control system required to regulate temperature and pressure
- "Bench top" set-up will need to be heavily modified to fit in vault
- Liquid lithium system much more hazardous than solid lens

Liquid Lithium Lens

Original Schedule

Phase	Goal	Completion Date
1a	Conceptual Design	12/31/97
1b	Produce drawings and report	3/31/98
2a	Assemble liquid lithium lens	12/31/98
2b	Design power supply	12/31/98
3	Test lens to 1,300 T/m, ship to Fermilab	12/31/99
4	Testing at Fermilab, build spare lens	6/30/00

Lithium Lens Upgrade

Summary

Solid lithium lens

Lens autopsy

Lenses 20, 21, 26 and Russian lens have been disassembled and analyzed
Lenses 17 and 18 will be analyzed in the next two months
Lens 16 and 22 will be disassembled in the next few months.

ANSYS modeling

Analysis complete on current lens design, refinements to model planned
Prototype lens analysis complete, report being generated

Prototype Lens

First prototype has been bonded, machining is underway, fill to follow
Second prototype is being designed with no central joint
First prototype will be tested to failure while second is being built

Quality Control

Lenses 27 and 28 have been assembled with the new techniques
Lens 27 has been filled with the new system
Titanium embrittlement being investigated

Liquid lithium lens

R&D effort may continue BINP

The liquid lithium lens is no longer expected for use in Collider Run II